



LONG DROPS

7 WHITE & AMBER PENDANTS RECTANGULAR CHANDELIER



DESCRIPTION

A modern and sleek multi-pendant light fixture comprising of four hand-made glass leaves encasing a dimmable LED bulb. Ideal for your kitchen island, reception, dining, bar, study area or any space that requires bright LED Dimmable lighting.

TECHINCAL SPECIFICATIONS

Designed by
AM Studio Team

Category
Pendant Chandelier

Canopy Finish
Powder coated metal in Flat White/ Sparkle Silver

Canopy Size
36"L x 12"W x 1.5"H

Pendant Colour
4 units of White
3 units of Amber

Pendant Size
3"W x 3"D x 16"H

Total Drop
5'H + 2' extra wire for adjustment

Bulb
MR16 LED - 12V

Recommended Dimming Switch
Lutron CTCL-153PD
Lutron Pro



Transformer:
Magnitude E60R12DC - 60W 12VDC - Dimmable - Class
2 LED Driver
Input: 120V
Output: 12V

Electrical Outlet needed: 1


Approx. Weight
8 kg

Catalogue # LD-7WA-36R


Note: Due to the nature of our handmade work, there may be slight variances in glass colour. AM Studio light fixtures are made to order, handmade and created in Toronto, Canada.



- Ⓐ x1 Bridge
- Ⓑ x1 Base
- Ⓒ x2 Support Rods (temporary mounting only)
- Ⓓ x2 Button Head Screws
- Ⓔ LONG DROPS - GLASS (See instructions page 3)



Separate (A) from (B)



Mount (A) to the ceiling.

Note: When mounting be sure to locate and mount (A) to a joist/ceiling beam


If you cannot do so, be sure to use drywall screws and anchors, drill additional holes for mounting for better support



Test lights by turning on power


Make sure bulb is not touching the glass!

Turn off power after testing




Connect electrical wire to the power

LONG DROPS Assembly Guide




Use support rods (C) provided to hang (B) off of (A)


Complete attachment with button head screws (D)



Remove rods (C) and attach (B) to (A) with the button head screws (D)



Attach the 2 narrow (2" wide) glass pannels (E) first
Pannel should hang freely, do not over-tighten




Attach the 2 wide (3" wide) glass pannels
Pannel should hang freely, do not over-tighten
 Make sure the glossy side is facing outwards

1.




- Dust the cord/rope/chain with a duster.

2.



- Hold the glass pendant/light fixture and gently wipe with a duster or microfiber cloth to remove dust.

3.




- For spot cleaning, use any good glass cleaner and a microfiber cloth.
⚠ Do **NOT** spray directly onto the light fixture/ glass pendant

4.



- Finish by gently wiping down the pendant with a soft, dry microfibre cloth.



Always use gloves when handling glass